




BISON GEAR

INEOS Grenadier Cargo Barrier Installation Guide

CARGO-GRND







Before you start






Before installation:

- Familiarize yourself with these instructions.
- Ensure that all listed parts and hardware are included in the package.
- Prepare a flat surface or floor with a minimum area of 1 x 1.5 meters.
- Gather the required tools.
- Installation requires two adults.








Part list

LP	PART	QTY	IMAGE
1	CARGO-GRND – Cargo barrier	1	
2	CARGO-GRND – Left extension	1	



3	CARGO-GRND – Right extension	1	
4	CARGO-GRND – Left headrest bracket	2	
5	Hinge	2	
6	Magnet	2	
7	Knob	2	



8	Flange bolt M6x12 ISO 7380-2	6	
9	Countersunk screw M6x16 DIN 7991	8	
10	Countersunk screw M5x20 DIN 7991	2	
11	Flat washer M5 DIN-9021	2	
12	Flange nut M6 DIN 6923	14	
13	Flange nut M5 DIN 6923	2	
14	Thread glue	1	




✂ List of necessary tools¹:

- 3 mm Allen Key (Hex)
- 4 mm Allen Key (Hex)
- 8 mm wrench
- 10 mm wrench
- Torque wrench

✂ Torque settings:


During assembly, use the recommended tightening torques for screw, unless other parameters are specified for a given connection.



¹ The tools **are not** included in the set.



BISON GEAR





BISON GEAR

Installation:

Before you start to work familiarize with the **Cargo Barrier Diagram (page 6)**. There is an exploded view that shows you how to install the cargo barrier.

Follow the steps below to install the product correctly:

***** Important**

It is recommended to apply thread-locking adhesive to all fasteners during installation. Place a small drop on each bolt before screwing on the nut.

1. Assemble cargo barrier and extensions using **M6x12 bolts** and **nuts**,
2. Screw the magnets using **M5x20 screws**, **M5 flat washers** and **M5 bolt**.
3. Pre-screw **the hinges** to the barrier using **M6x16 bolts** and **M6 nuts**.
4. Remove the **headrest of your car** and put the **headrest bracket** on them (put the cylindrical parts into the bracket's holes) and install it back.

***** Important**

The cargo barrier installation requires the Bison Gear cargo shelf. Pre-drilled holes are provided to fit this product.



BISON GEAR

5. In the next step you must have **assist of one adult person** who will hold the cargo barrier during the mount. Put the **cargo barrier** to the car and screw it to the Bison Gear Under-the-Roof Shelf using **M6x16 screws** and **nuts**.
6. Screw the knobs into the headrest bracket (there are 3 oblong holes, choose the best for you).
7. Regulate the **vertical** and **horizontal position** of the shelf and **screw all the bolts**.

Make sure that everything is mounted properly, and all the bolts are tightened. If it everything is correct, your work is done.

After driving 50km, check all the bolts and re-tighten them if necessary.



BISON GEAR

Have a great time with Bison Gear products!



Email: contact@bison-gear.com

Phone: **+48 505 642 981**